

XTcOS

Proof of concept of a community driven operating system (or call it firmware or distribution) for the Xtremer.

Versioning

Since we heavily base on the official firmware, or in other words we just slightly modify this, we use their firmware release number in ours, too. The releases are called `xtcos-<Xtremer Firmware Number>-<Our Patchlevel, increased by every fw xtcos release>`.

XTcOS-2.2-3

Released at 2010-02-12, [XTcOS-2.2-3](#) (md5sum 2ce3c2b8dfc9efa3dbe7aecef7d6ea15)

Important note about hardware detection:

In this release we changed the hotplug binary to add our `xtcos-hotplug-config` feature. During this process we used the wrong hotplug sources and so not this hotplug agent misses the detecting of the wifi adapter (and maybe more). But you can easily change this since the original hotplug binary is in the firmware, too:

```
~ # ls -al /sbin/hotplug*
-rwxr-xr-x  1 root  root           57324 Feb 12 13:59 /sbin/hotplug
-rwxr-xr-x  1 root  root           64192 Feb 12 14:27 /sbin/hotplug-
fw-2.2
```

So make a backup of our new one and copy the one from `fw-2.2` to `/sbin/hotplug`:

```
~ # cp /sbin/hotplug /sbin/hotplug-xtcos-2.2-3
~ # cp /sbin/hotplug-fw-2.2 /sbin/hotplug
```

We will release a fixed hotplug in the next few days.

Installing

See notes from further XTcOS releases, it is an emergency firmware.

Major Changes To XTcOS-2.2-2

- kernel got new modules for the rtl8192u wifi adapter, added `CONFIG_SYN_COOKIES=y` for the arno firewall
- added `sylfsutils` just to see some more human readable informations about our plugged in

devices

- xtcos-hotplug-conf.sh no working for: arno-firewall, samba, lighttpd, stupid-ftp and udhcp
- added basic firewall setup with granted access from local network (see below)

Other features see the notes from further XTcOS releases

Basic Firewall Setup

By default we activated the arno-firewall. The default config is:

```
## 2010-01-12 by nixda
#
# This is a simple configuration for arno's iptables firewall, see
#
http://rocky.eld.leidenuniv.nl/joomla/index.php?option=com_content&view=article&id=45&Itemid=63
#
# For our simple setup you may not need to change anything if you want to
grant access
# to your box from (only) all IPs of the local network. Therefore I have
added this
# switch GRANT_LOCAL_NET to arno's firewall script:

GRANT_LOCAL_NET=1

# Sometimes you may want to add further hosts (not in the range of your
subnet)
# to grant full access, too. If so then just add something like this
FULL_ACCESS_HOSTS
# rule:
#
# FULL_ACCESS_HOSTS="192.168.100.2"

# You may add change a lot of more rulesets. arno's firewall is _very_
powerfull.
# If you don't know exact how things go on you may not change anything.
#
EXT_IF="eth0 wlan0"
EXT_IF_DHCP_IP=1
EXT_OPEN_ICMP=1

ENV_FILE="/share/arno-iptables-firewall/environment"
PLUGIN_BIN_PATH="/share/arno-iptables-firewall/plugins"
PLUGIN_CONF_PATH="/usr/local/etc/arno-iptables-firewall/plugins"
```

You can easily change this configuration by editing the file `/usr/local/etc/arno-iptables-firewall/firewall.conf`. If you want to use the XTcOS hotplug configuration just put the config on an external storage device (f.e. usb stick) and plug it to the xtremer. The config file must not be in any subdirectory and its name must be `xtcos-hotplug-arnofirewall.conf`.

xtcos-hotplug-conf.sh Version 0.2

With this release we add for the first time a simple util to configure some deamons, service via configuration files you put on your usb stick. The idea behind is that you are able to config the firewall even you made a big mistake first and have no more access to the box via network. And since right now we have not keyboard, monitor I thought this way to configure may not be a failure.

Right now these services can be configured: The arno's firewall, Samba, lighthttpd, stupid-ftp and udhcpc. The configfiles for these services must be named as following:

```
xtcos-hotplug-arnofirewall.conf
xtcos-hotplug-samba.conf
xtcos-hotplug-lighthttpd.conf
xtcos-hotplug-stupid-ftp.conf
xtcos-hotplug-udhcpc.script.conf
```

You need to put these files on the first storage device (so called sda1)!

By default xtcos-hotplug-conf.sh makes a backup and a diff of your old config including a timestamp (xtcos-hotplug-<service id>-<timestamp>.conf.bak and xtcos-hotplug-<service id>-<timestamp>.conf.diff). A short report will be found in file xtcos-hotplug-conf-report-<timestamp>.txt. Your new config will be renamed to ...-<timestamp>.done.

Just two notes: Be aware to not put CR+LF for newlines in. Just use LF like used in the unix world! To affect the changes for udhcpc you may reboot.

Know Problems

- poorly we have not that much hardware to do some more tests. If you want to donate... let me know. ;)

XTcOS-2.2-2

Released at 2010-02-10, [xtcos-install-2.2-2.img.bz2](#) (md5sum 6411357dc38557706354afacad70bc4d)

Installing

See notes from XTcOS-2.2.b5-0, it is an emergency firmware.

Major Changes To The Xtreamer Firmware

- busybox-1.16 with a lot more implemented features like tar with gzip, md5sum...
- added tools like strace, file and unrar
- like the first release we added a lot of kernel modules (and kernel config see /proc/config.gz
- prepared for pivotroot

- crond added (running per default)
- increased root partition size, reduced partition for /usr/local/etc

Other features see the notes for XTcOS-2.2.b5-0.

Know Problems

- Wifi is broken! Will be fixed soon (expected at 2010-02-13)
- The hotplug util from Xstreamer is not flexible enough. So we can't hook in with our new config util `xtcos-hotplug-conf.sh` right now.
- Xstreamer changed their kernel or kernel config but we don't know what they did. So unsure if our miss anything (one note: the kernel modules for the wifi adapter changed a lot).

XTcOS-2.2.b5-1

In general this release offers further kernel modules, a new busybox-1.16 and some more utils, binaries. The step after this release will contain some very smart install and configure options... stay tuned!

This version was only for some internal tests.

XTcOS-2.2.b5-0

WARNING

Xstreamer comes with a opened firmware so everybody in your network can take control of your xstreamer within seconds. Our distribution is not secure, but we fixed some big holes and put utils in your hand to go on.

Right now this release has a default password for the root access for ssh (which is running!). The password is `xtcos`.

DO NOT PLUG YOUR DEVICE IN FOREIGN NETWORKS

Further `xtcos` versions - if there will be one - will come with a `iptables` config to only allow access from local network(s).

Installing

Download [xtcos-install-2.2b5-0.img](#) (md5sum 96880550fdb513f74014d4d50db25a78), unzip (bunzip2) the file, rename it to `install.img` and follow the instructions from Xstreamer for an emergency flash (shutdown Xstreamer, unplug power for about 10 seconds, plug in power, press the following key one behind the other (on the RC): Home, 3, Power).

Until now we did not brick any of our Xstreamers. But all risk is on your side!

Major Changes To The Xtreamer Firmware

We used an inofficial beta version 2.2.b5 for this test. As soon as Xtreamer will release a new firmware we think of patching that too and releasing a new XTcOS.

- Kernel changed, mainly with added iptables functionality and SMART patch
- Added openssh
- closed the open access to samba shares

Know Problems

- Isoc not working with a „/sbin/lsof: /sbin/lsof: 1: Syntax error: Bad function name“

Added Functionality And Changes

Samba

The diff of the smb.conf:

```
@ -1,3 +1,4 @@
 [global]
 -security=share
 +smb passwd file=/usr/local/daemon/samba/lib/smbpasswd
 +security=user
   include=/usr/local/etc/workgroup
@@ -9,4 +10,4 @@
   use sendfile=yes
 -guest account=root
 -#encrypt passwords=yes
 +guest account=nobody
 +encrypt passwords=yes
   passwd backend=smbpasswd
@@ -26,3 +27,4 @@
   path=/tmp/usbmounts/
 -guest ok=yes
 +username=root
 +browsable=yes
   writable=yes
```

So the first time you should add a useraccount (f.e. root, whatever) to the smb passwd file with

```
/usr/local/daemon/samba/sbin/smbpasswd -a root
```

/etc/passwords

Only root get a shell and user sync has /bin/sync, the others /bin/false. All accounts but root are

locked. It seems Xtreameer does not use/need them... we will see. In the Xtreameer there is not something like a usermanagement because everything runs as root. You and we can change this but it takes some time. So if you like to contribute...

Linux

We added a lot more modules to play and test. vpeter contributet a patch to get smart values from the sata interface. The kernel should be ready to boot a rootfs from a internal hdd but I just have not one to test. To see how the kernel is configured have a look at /proc/config.gz (added feature, too). Who likes the .config file?

The modules we put in all alle gzipped to save space on flash. So for this we needed to replace the module-utils from Xtreameer with our own (Xtreameer used some of busybox).

OpenSSH

OpenSSH is installed and running by default. Be aware: Root logins are permitted!!!

Iptables And Firewall Scripts

The kernel is ready for and we added a lot of netfiltermodules. To play around we added the [arno-iptables-firewall](#) environment, too. We just not finished in customizing this. Maybe we change this util with another, unsure right now.

Utils Added/Changed

in /sbin:

- depmod
- modprobe
- insmod
- iptables (some binaries, symlinks)
- lsof
- modinfo
- rmmod
- sshd
- sysctl
- zntpdate

in /bin;

- lsmod
- scp
- sftp
- ssh
- ssh-agent

- ssh-keygen
- ssh-keyscan

Init Script/Runlevel

I would say that in my opinion it is not a really good idea that the Xtreamer uses the binary DvdPlayer for a lot of things to initialize and configure. So there is no chance, no way to put something into the xtreamer that looks anything like a real management of services or runlevels like we know it from well designed LSB conform distributions.

So for a first step we take /etc/udhcpc.script as a starting point to sync the time or start sshd for example. I don't like that, too.

Timesync

We start zntupdate from the /etc/udhcpc.script. Just have a look there to make sure it uses the right time/timezone...

Wishlist For New XTcOS

- ~~add strace~~ added with xtcos-2.2-2
- ~~add smart firewall setup (I suggest more like a personal firewall would be nice)~~ added in xtcos-2.2-2 (xtcos-hotplug-conf.sh) but hotplug hook missing
- ~~add gunzip/bunzip2 (a must!)~~ added with xtcos-2.2-2
- ~~add rar/unrar (a must!)~~ unrar added with xtcos-2.2-2, rar maybe will not get into xtcos
- ~~add better tar with gzip/bzip compression~~ added with xtcos-2.2-2
- ~~new/better hotplug with ability to add pre and postexec script for usb plugged devices~~ a very basic hat is in since xtcos-2.2-3. But that is not so nice...
- stability/performance of the wlan interface
- use of innittab and runlevels (init from busybox is ready for)
- ~~add a nice, small example config for the arno firewall~~ added with xtcos-2.2-3
- add lsof (no prebuild ipkg package unless it only uses our libs!)
- test pivotroot with internal hdd and or on other usb mass storage device

a last word...

You see we only modified some few parts (f.e. where we have the source code) and there is not that much space left on flash to put other big projects in it. Our intension is more in add a harddisk and put the rootfs there. This wouldn't be that hard but sadly for that everybody needs a serial cable and must modify the bootloader config. Another idea would be to patch linux so this will boot from hdd or use the pivotroot environment. It is up on you to decide how it will go on... Contributions are welcome!

From:

<https://www.wissipedia.feindas.de/> - **Wissipedia - eine Feindas.DE Initiative**

Permanent link:

<https://www.wissipedia.feindas.de/xtcos?rev=1266060057>

Last update: **2010/02/13 11:20**

